

# Filter Pocket Directions for EYMM Cloth Face Mask & N95 Cover

This is a modification for the [EYMM cloth face mask pattern and N95 cover](#) to add a pocket for additional filtration layers approved by the facility using them. **This mask is NOT a medical device and can not prevent CoVid19**, but it meets standards set by the CDC when no other personal protective equipment is available.



This is not the same format as my normal patterns because I wanted to get it out quickly for all the people ready to start sewing and donating!

*This pattern is FREE to download and use for personal and charity (donation) use. Don't use this pattern to sell masks to during a pandemic, that is not what this was created for and it is just not cool. There are other patterns out there you can use for that.*

*Finally please do not redistribute it without permission, while it is free I worked hard to create this and may need to edit it etc. You are welcome to print off 5 copies, or such, for the ladies in the church group who can't, but otherwise please just link people back to this tutorial [www.eymm.com/masks](http://www.eymm.com/masks).*

© 2020 Everything Your Mama Made & More!



## SUPPLIES:

Supplies are the same as the original pattern, but you cut 2 each of the attached lining pieces instead 2 of the original.

This modification tutorial replaces STEP 5 in the original directions.



### POCKET STEP 1:

On your 2 center pieces straight sides, and your 2 wing pieces long sides, use your iron to press wrong sides together  $\frac{1}{4}$ ", and then repeat one more time another  $\frac{1}{4}$ " to create a narrow hem. Stitch in place with  $\frac{1}{8}$ " from the edge. You should now have 4 pieces that all have one hemmed edge.



### POCKET STEP 2:

With right sides together, sew using a  $\frac{1}{4}$ " seam allowance, along the curved edge of the center pieces.

For the best results clip along your curve, making sure not to hit your seam. This is not a must-do if production sewing for donation, but it will give a nicer finished seam.





**POCKET STEP 3:** (NOTE: These are tester photos, your elastic/ties should already be attached from step 4)

With right sides together line your center piece up and pin it to your main.

Lay your wing pieces out on the correct sides.



**POCKET STEP 4:**

Lay your wing pieces in place and pin. They will overlap on top of your center lining panel by at least 1/4".

Your ties and elastic should be in between all the layers like on Step 5 of the original pattern.



**POCKET STEP 5:**

Stitch completely around the outside. No need to leave an opening, the pocket does this for us!

Clip the corners like original pattern for the best finished results!

**POCKET STEP 6:**

Using your pocket, turn your mask right side out and press. For the best finish Top stitch around the mask 1/8" from the edge.



## Your Finished!

Please note this tutorial was done with tester pictures, we changed the style of elastic for a better fit.

Adult XL

Adult

# Pocket Lining Face Mask N95 Cover

## Center Pocket Lining

Cut X2 Lining (mirror image)  
100% Cotton



# 3" Test Square

**This pattern is for personal & charity (donation) use ONLY.**

Do not redistribute without permission, link people to [www.eymm.com/masks](http://www.eymm.com/masks) to download and print their own copy.

Pocket Lining Face Mask  
N95 Cover

Wings Pocket Lining

Cut X2 Lining (mirror image)  
100% Cotton

**This mask is NOT a medical device and can not be used to prevent CoVid19.**